ProBase

Installation guide

Install your interlocking shed base on firm, level ground.



1 Prepare the sub-base

Clear an area slightly larger than your ProBase. You can lay it on short, level grass, gravel or bare soil. The surface must be firm, compacted and level. Where possible, remove the turf so you can check the ground underneath.



2 Lay out the membrane

Lay the supplied permeable weed membrane over the prepared area. Cut or fold it to fit.

Levelling tip If needed, spread 10 mm round pea gravel over the membrane and rake it level.



3 Interlock the grids

Lay the grids over the membrane with the feet facing down. Align the clips and press the grids together to lock them. To separate them, use a screwdriver as a lever to release the clip.



Align clips



Clip locked



Release clip



4 Add gravel if needed

Use 10 mm round pea gravel. Each grid holds approximately 12 kg. For log cabins and large sheds, fill the perimeter grids. For heavy-duty buildings, poor ground or installations on grass, fill every grid, working from the outside in.

On grass Avoid walking on the grids until they are filled with gravel.