EcoBearer

Installation guide



Fit the EcoBearers to the underside of your shed floor before positioning it on site.



1 Snap on the EcoBearers

Turn the shed floor upside down so the timber runners face up. Snap the EcoBearers onto the runners.



2 Fix with the screws provided

Drive the supplied screws through the EcoBearers and into the timber runners. Finish tightening by hand.

Using a power screwdriver? Avoid overtightening.



Level grass



Soil



Completed shed on EcoBearers

3 Position the shed floor

Turn the floor right side up and set it on a level surface: grass, soil, tarmac or concrete. Anchor the base if required.

4 Build your shed

Once the floor is in its final position, assemble the shed following the manufacturer's instructions.